


SUB PCB(DISPLAY)

SCHEMA




WIRING DIAGRAM


⚠ WARNING

To avoid risk of electrical shock, personal injury or death; disconnect power to washer before servicing, unless testing requires power.

Model : WA5471*, WA5451*

SCHEMATIC DIAGRAM





SCHEMATIC DIAGRAM

PCB SUB(DISPLAY)

PCB MAIN CONTROL

